

DOWNLOAD THE LATEST INSTALL MANUALS AT www.bddiesel.com



Variable Vane Exhaust Brake

Ford 6.4 Powerstroke F250/F350/F450/F550 2008-2010



PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLATION

Kit Contents

Please check to make sure that you have all the parts listed in this kit before you start the disassembly of your truck.

21	100020	130	1301810		2000107	1301812
	THRAIST BERNEA		BD			THAT BEARING
6.4 VVB Module/Harness		s Push But	Push Button Switch		Switch Bracket	Switch Decal
Qty: 1		Qt	Qty: 1		Qty: 1	Qty: 1
1330053	FT-10910- 03116	1300349	1300131		1330052	1330054
Alkohol						A VALUE OF THE PARTY OF THE PAR
Alcohol Swab	Velcro	Posi-Tap 12-18awg	Cable Tie	es	Screw	Tape; DS
Qty: 1	Qty: 2 pcs	Qty: 1	Qty: 8		Qty: 2	Qty: 1

Tools Required

- Socket 8mm or 5/16"
- Utility knife

- Side cutters
- Optional tools for switch installation
- Drill & Bits
- Stepper bit or small hole saw
- Small file

Related BD Products

TapShifter 6.4L

The BD 6.4 TapShifter is a great compliment to the Variable Vane Exhaust Brake. The TapShifter allows you to downshift with ease, disable overdrive or take manual control over gear selection. This aids in engine braking and is very helpful for towing.



Turbo Thruster 6.4L Twins

Ford 6.4 engines have twin turbos from factory. This BD upgraded twins kit supports 600-750hp while maintaining a drop-in factory style turbocharger setup. The turbos have upgraded billet compressor wheels, a built in velocity stack and a new air intake. Compatible with the BD VVB.

1047080 2008-2010 6.4L Ford



Introduction

The BD Variable Vane Exhaust Brake for the Ford 6.4 utilizes the vehicles stock VGT turbocharger as an engine exhaust brake. The module closes the turbochargers exhaust vanes to restrict exhaust flow, thus building exhaust backpressure and retarding the engine during deceleration conditions. The module also has the ability to command transmission downshifts to improve engine braking capabilities.

The kit installs with a series of plug in connections in the engine bay and in the vehicle cabin. This makes the entire installation process much simpler when compared to conventional exhaust brake installations.

Operation

The BD Variable Vane Exhaust Brake is controlled automatically when turned on. There are two different operating modes the driver can select using the push button switch mounted on the dash.

mounted on the dash.					
BD	Off	The truck operates normally with no additional holdback.			
BD	Mode 1 Braking Only	This mode closes the turbocharger vanes during deceleration. This does not alter the transmission gear or turn on tow/haul. To achieve maximum holdback, increase engine RPMs by shifting to lower gears during deceleration.			
BD	Mode 2 Braking & Shifting	This mode closes the turbocharger vanes during deceleration and also down shifts the transmission once the brake pedal is pressed.			


Special Note

Do not use mode 2 in adverse weather conditions

Installation

- 1. Block wheels to secure vehicle and disconnect negative battery cables for safety. (Record radio settings for customer before battery disconnect.)
- 2. Separate the VVB wiring harness at the small white connector. The harness and module on the left will be installed in the engine bay. The harness on the right will be installed in the vehicle cabin.

Familiarize yourself with the connections before beginning installation.



3. Remove the knee bolster by pulling rearward.




4. Remove the top cover on steering wheel column, locate and disconnect tow/haul connector. Feed the BD harness connectors up from behind the dash and Install the BD harness between the OEM connectors. Replace top cover onto steering column.

If your truck is equipped with a manual transmission skip this step as the tow/haul function does not apply to your vehicle. The VVBs tow/haul harness is not used in a manual transmission application so simply secure it out of the way under the dash and proceed to step 5.




5. Locate the factory purple w/ white tracer wire that connects to the brake pedal switch below the dash. Attach the white wire from the BD harness to it using one of the supplied posi-tap.










Install push button switch and connect to the BD wiring harness.


OPTION 1 – SWITCH IN DASH

Drill a 7/8" hole in the dashboard with a stepper bit or hole-saw. Using a small file, create a notch for the locator tab of the switch. Clean up the edges of the hole as necessary with the file. Mount supplied switch decal onto the dash, aligning the notch on the decal with the notch you created. Install switch into the hole and connect to the BD harness.



OPTION 2 – SWITCH BRACKET

Install the switch decal onto the bracket, aligning the notch on the decal with the notch on the bracket. Using supplied scews; fasten the bracket to the dash in a suitable location. Finally, install the switch into the bracket and connect to the BD harness.



7. Feed the remaining end of the in-cabin wiring harness through the firewall into the engine bay. If additional wires have already been routed through the firewall, follow these wires. Otherwise use the existing rubber grommet.



8. Clean the back of the module and top of fuse cover with the supplied alcohol swab. Secure the module to fuse cover lid using supplied Velcro.




9. Connect the in-cab wiring harness to the control module in the engine bay by plugging in the small eight pin white connector.



10. Route the BD harness towards the brake hydro-booster. Disconnect the two wire master cylinder pressure switch. The connector is on the bottom of the master cylinder.






Note There are two connectors on the bottom of the master cylinder. The correct connection is the one towards the front of the vehicle.



 Disconnect the turbo vane actuator. Connect the BD harness to actuator and OE plug.





- 12. Secure wiring harness away from moving parts and heat sources using the supplied cable ties.
- 13. Reconnect negative battery terminals and ready vehicle for road test.
- 14. Road test vehicle to verify operation of VVB.

Troubleshooting

