
2753 Michigan Road • Madison, Indiana 47250 • 855-743-3427

INSTALLATION INSTRUCTIONS

Heavy Duty Radiator:
for Polaris® General™





- ***Avoid burns and scalding by working on cool vehicles.***
- ***Use manufacturers recommended coolant.***
- ***Verify that no leaks are present after installation.***

CUSTOMER NOTIFICATION AND DISCLAIMER LIABILITY

This product is a modification for utility task vehicles and all terrain vehicles. Use this product at your own risk.

Warranty and Liability Limitations. The Buyer hereby assumes all risks associated with the use and/or installation of this product. Buyer waives all liability claims against SuperATV® of any kind or nature, including, but not limited to, liability for penalties, fines, property damage, personal injury or death, to the fullest extent permitted by law. Buyer acknowledges and agrees that SuperATV® is not liable for any direct, indirect, incidental, consequential or special damages, including but not limited to, damage, loss of life, loss of property or equipment, loss of profits or revenue, injury, or claims from any individual or entity arising from the use of this product.

The warranty for this product, if any, may give you ("Buyer") specific legal rights, and Buyer may also have other rights which may vary from state to state. The installation of this product may void or otherwise adversely affect your factory warranty.

Consult your vehicle warranty before using this Product. Under no circumstances will SuperATV® be liable for the voidance of the Buyer's vehicle warranty. Buyer assumes all risk and responsibility if a manufacturer and/or dealer voids the Buyer's vehicle warranty due to use of this Product.

Safety and Laws. Operate your vehicle at all times in a safe manner. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you. The installation of this product may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of this product on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of this product. In no case will SuperATV® be held liable if Buyer violates the law or uses the product in an unsafe manner.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.

Installation. The installation of this product on your vehicle indicates that you have had the opportunity to inquire about applicable local, state, and federal laws and ordinances and that you have read and understand, and accept all of the terms of, this Disclaimer.

SuperATV® shall not be responsible for the proper installation, use, and service of this product. Rather, the Buyer shall be solely responsible for the installation of the product and any damage that may be done to the vehicle or vehicle components as a result of modifications made by the Buyer.

Need help with your installation?

sales@superatv.com

www.superatv.com

1-855-743-3427

8:00am - 8:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday

Read instructions and view illustrations before beginning.

Thank You For Choosing SUPERATV.COM®


© 2020 SuperATV.com®. All Rights Reserved.


Remove Hood


remove Push Pins shown
remove hardware




- Pull Fenders away and push Hood Liner up.





- Remove passenger side Wheel.





(1)
clamp Hose to minimize
coolant loss
(driver)


(driver)
(2)
disconnect Hose
POLARIS




remove Radiator/Fan assembly

- Install Lower Mount and secure to Frame with hardware shown.




- Transfer stock Fan to new Radiator. Secure with stock hardware.



4 Seat Model only:


- Install Side Mount to Radiator with M6 x 20mm Bolts.



- Fan will secure to Side Mount with hardware shown.




- Remove hardware shown.



- Rotate Solenoid Bracket up as shown; reinstall hardware.




Shroud Trim








- Install Radiator and Upper Mounts.



- Lower Hood Liner back into postion. Do not secure.

- Hood Liner must be trimmed for proper Surge Tank Fitting clearance.



- Mark Surge Tank Fitting interference location onto Hood Liner.



- Remove material from Hood Liner.



- Secure Hood Liner with stock components.
- Reconnect stock Hoses and Surge Tank Tube to new Radiator.
- Reconnect Fan Wire Harness.
- Reinstall upper portion of SuperATV Bumper if applicable.
- Follow manufacturers recommendations and add Coolant. Refer to Service Manual and flush Cooling System.
- Reinstall Hood and Wheel.