
2753 Michigan Road • Madison, Indiana 47250 • 855-743-3427


INSTALLATION INSTRUCTIONS

Heavy Duty Rack and Pinion:
for Kawasaki Teryx® KRX™

Do not discard packaging until product has been successfully installed.




Rack and Pinion




Hardware Kit


2 x Tie Rod Shaft
SKU HDRP-K-KRX



2 x Tie Rod Shaft
SKU RP-K-KRX



2 x Tie Rod Shaft
SKU SDRP-K-KRX



2 x Ball and Socket

2 x Tie Rod End and Jam Nut



SKU RP-K-KRX only see page 6:

Only install if SuperATV Forward Offset A-Arms or Lift Kit are present.



2 x Steering Stop



Wire Ties

Need help with your installation?

sales@superatv.com

www.superatv.com

1-855-743-3427

8:00am - 8:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday

Read instructions and view illustrations before beginning.

Thank You For Choosing

© 2021 SuperATV.com®. All Rights Reserved.

Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.


By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.


SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warrantied if item was not installed properly, misused, or modified.


Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.


The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.




Disconnect Tie Rod.
(Passenger)



PASSENGER SIDE ONLY
remove Acuator Cover




Separate Front Differential from Drive Shaft
(Driver)



Remove stock Rack and Pinion hardware.


- Remove hardware from Steering Shaft.
- Remove Steering Shaft from Rack and Pinion.




Steering Stop installation (Rack and Pinion shown off machine for clarity only)

- Remove Boot.
- Install Steering Stop onto Shaft.
- Reinstall Boot.
- Repeat steps for opposite side.











- Reinstall Steering Shaft to Rack and Pinion.
- Reattach Front Differential to Drive Shaft and Frame.
- Install Tie Rods; see following page.

- Install Tie Rod Shafts to Ball and Sockets on Rack and Pinion.
- Install Tie Rod Ends to Tie Rod Shafts.
- Secure Tie Rod Ends to same location as stock on Spindles with hardware shown.





Cotter Pins install after Nuts have been installed



- Before initial ride, set toe-in of vehicle.
- After initial ride check to see that hardware remained tight.

This page applies to SKU's SDRP-K-KRX and HDRP-K-KRX only.





- Inner Tie Rod End is adjustable and can be tightened.
- Remove Clip and loosen (4) Set Screws
- Screw Inner Tie Rod End into Cup.