2753 Michigan Road • Madison, Indiana 47250 • 855-743-3427

INSTALLATION INSTRUCTIONS


Gen 3 Portal Gear Hubs - 6”

Can-Am Outlander/Renegade (Gen 2)

Do not discard packaging until product has been successfully installed.

Item	Description
A	Rotor x 4
B	Left Gear Box x 2
C	Right Gear Box x 2
D	Gasket x 4
E	Cap x 4
F	Front Recessed Nut x 2
R	Rear Recessed Nut x 2

(Kit Contents continue on following pages)



PGH607-GB455B





PGH607-GB451B






PGH607-GB455A







PGH607-GB451A

WHEN FILLING GEAR BOX USE ONLY SUPERATV PORTAL BLOOD. USING GREASE WILL CAUSE FAILURE OF GEARS AND BEARINGS. USING GREASE WILL VOID THE WARRANTY.

Need help with your installation?

sales@superatv.com
www.superatv.com
1-855-743-3427
8:00am - 8:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday


Read instructions and view illustrations before beginning.

Thank You For Choosing

© 2018 SuperATV.com® All Rights Reserved.

Rev IN-PGH6-7-13-451 ~ IN-PGH6-7-13-452 7/19/2024

(Kit Contents continued)






Item	Description
G	Caliper Mounting Bracket x 3
H	Left Spindle
J	Right Spindle
K	Left Trailing Arm
L	Right Trailing Arm
M	Left Steering Arm
N	Right Steering Arm







(Left)






(Right)

PGH6-7-13-451 Brake Lines & Fitting

Location	Length (Approx)
T-Fitting to Handlebar	19-1/4”
T-Fitting to Right Front	60”
T-Fitting to Left Front	
T-Fitting to Rear Cylinder	58-1/4”
Rear Cylinder to Right Rear	46”



PGH6-7-13-451 Fitting
no hardware needed;
Wire-Tie if desired.

PGH6-7-13-452 Brake Lines

Location	Length (Approx)
Right Front	42”
Left Front	46”
Right Rear	57”

Machines with SuperATV Heavy Duty Tie Rod Ends must use provided hardware shown when securing to Steering Arms.



M12 Nylock Nut



M10 Nylock Nut




M12 Nylock Nut

(Qty. 2 each)

Read ALL instructions prior to operating Portal Gear Hubs. Injury to personnel, portal gear hub, and/or machine failure may be caused by improper installation, maintenance or operation.
• It is dangerous to get under a jacked-up vehicle. The vehicle could slip off the jack and fall on you. You could be crushed. Never place any part of your body under a vehicle that is on a jack. Never start or run the engine while the vehicle is on a jack. If you need to get under a raised vehicle, take it to a service center where it can be raised on a lift.
• Hot oil can cause severe burns. Use extreme care when removing lubrication plugs and when working close to a unit that has been in operation.
• Check lube level between scheduled lube changes to insure that proper lube level is maintained. Inspect the tightness of mounting bolts, excessive heating, or any unusual noise or vibration.
• Serious personal injury may occur as a result of improperly performed maintenance, adjustments or repairs.
• Always be extremely careful when working on the portal gear hub. Always follow commonly accepted safety practices and general common sense. Never risk personal injury.
• Do not operate the portal gear hub without proper lube and correct amount.


For safe operation and to maintain the unit warranty, when changing a provided fastener for any reason, it becomes the responsibility of the person making the change to properly account for fastener grade, thread engagement, load, tightening torque and the means of torque retention.
• Mounting bolts should be periodically checked to ensure that the unit is firmly anchored for proper operation.
• These instructions are not intended to cover all details or variations in equipment, nor provide for every possible contingency to be met in connection with selection, installation, operation, and maintenance.
Should further information be desired or should particular problems arise which are not covered sufficiently for the Buyer's purpose, the matter should be referred to SuperATV®.

In the event of the resale of any of the goods, in whatever form, Resellers/Buyers will include the following language in a conspicuous place and in a conspicuous manner in a written agreement covering such sale:
The manufacturer makes no warranties or representations, express or implied, by operation of law or otherwise, as to the merchantability or fitness for a particular purpose of the goods sold hereunder. Buyer acknowledges that it alone has determined that the goods purchased hereunder will suitably meet the requirements of their intended use. In no event will the manufacturer be liable for consequential, incidental or other damages. Even if the repair or replacement remedy shall be deemed to have failed of its essential purpose under Section 2-719 of the Uniform Commercial Code, the manufacturer shall have no liability to Buyer for consequential damages.
Resellers/Buyers agree to also include this entire document including the danger, warnings and cautions above in a conspicuous place and in a conspicuous manner in writing to instruct users on the safe usage of the product.



Numbers on Lid and Housing MUST match.
Stop and contact SuperATV if different.


install into each Gear Box
Torque to 10 ft/lbs



Drain Plug

DO NOT USE IMPACT WRENCH WHEN INSTALLING ANY HARDWARE INTO HOUSING


if not present, install hardware shown




2x

M12 x 55mm


Torque to 60 ft/lbs MAX



Front Components Removal: *Keep all components removed from machine.*



Rear Components Removal: *Keep all components removed from machine.*


(Right Side)


Remove:

- **Sway Bar from Trailing Arms**
- **Shocks from Trailing Arms**
- **CV Guards; *will not be reinstalled***
- **Axle Nuts and Pins**
- **Brake Line from Trailing Arm**
- **Caliper and Disc**
- **Hubs**
- **Trailing Arms**


(Left Side)

All Non XMR Outlander/Renegade (Gen 2) machines must remove stock Brake Lines

Stock Brake Lines and Fitting are (1) component and must be replaced with provided Brake Lines and Fitting. *Installer may cut stock Brake Lines from stock Fitting* or remove as (1) component.





Option:
- **Disconnect Brake Lines from Calipers, Handlebar, and Rear Master Cylinder.**
- **Remove Brake Line Clips.**
- **Cut Brake Lines from Fitting.**
- **Remove Brake Lines from machine.**
- **Remove Fitting from machine.**


(Brake Lines Removal illustrations continue on following pages)

Remove following components from machine.












Remove Brake Lines from Rear Master Cylinder.






Remove Clips from Frame and Brake Lines.





Remove Brake Line from Handlebar.




Remove hardware from Coolant Tank and Air Intake Hose.








Pull Brake Lines up and out of machine.



Remove Fittings and Brake Line from machine.


Install provided Studs into Rotors (A):
- See “Wheel Hub Bolt Patterns”.
- Note machines bolt pattern and lug size.
- Set Rotors (A) aside when complete.








Wheel Hub Bolt Patterns



Pattern	Machine	Diameter
A	Polaris	156mm
B	Can-Am/Teryx4	137mm
C	Arctic Cat	115mm
D	Honda/Yamaha	110mm

Front: *do not tighten hardware completely unless noted.*


- Secure Right Spindle (J) to A-Arms with stock hardware.
- Secure Right Steering Arm (N) to Right Spindle (J) with hardware shown.
- Secure Tie Rod End to Right Spindle (J) with stock hardware.



Repeat steps for opposite side and tighten all hardware completely.

Front continued:


- Install Right Gear Box (C) onto stock Axle.
- Secure Right Gear Box (C) to Right Spindle (J) with hardware shown.
- Install Caliper Mounting Bracket (G) to Right Gear Box (C) with hardware shown.



Tighten all hardware completely and repeat steps for opposite side.

Front continued:

- Secure stock Axle with Front Recessed Nut (F); use thread locker.
- Secure Gasket (D) and Cap (E) to Gear Box (B) with hardware shown.
- Secure Rotor (A) to Gear Box Axle Shaft with hardware shown.



- **Torque to minimum 300 Ft/Lbs.**
- **Continue tightening until Cotter Pin can be installed.**

Tighten all hardware completely and repeat steps for opposite side.

See tables on page 3 for correct Brake Lines to install.

Install Front Brake Lines:


- Reinstall Brake Calipers to Caliper Mounts (G) with stock hardware. Tighten completely.
- Follow stock routing when installing.
- Secure to A-Arms with provided Brake Line Clips and hardware.
- Ensure no binding or interference can occur when in use.


Rear: *do not tighten hardware completely unless noted.*

- Install Left Trailing Arm (K) to machine with stock hardware.
- Secure Shock and Sway Bar Link with stock hardware.
- Tighten hardware completely and repeat for opposite side.

SuperATV recommends using Loc-Tite on Nuts when installing components.








Rear continued:

- Secure stock Axle with Rear Recessed Nut (R); use thread locker.
- Secure Gasket (D) and Cap (E) to Left Gear Box (B) with hardware shown.
- Secure Rotor (A) to Gear Box Axle Shaft with hardware shown.



- **Torque to minimum 300 Ft/Lbs.**
- **Continue tightening until Cotter Pin can be installed.**

(Left Side)




Tighten all hardware completely and repeat steps for opposite side.



See tables on page 3 for correct Brake Lines to install.


Install Rear Brake Line:

- Reinstall Brake Caliper to Caliper Mount (G) with stock hardware. Tighten completely.
- Follow stock routing when installing.
- Secure to Trailing Arm with provided Brake Line Clips and hardware.
- Ensure no binding or interference can occur when in use.



Tighten all hardware completely.

- Attach a hose to a funnel and fill each Gear Box with SuperATV Portal Blood.
- Fill up to fill hole.
- Install Drain Plug.



Drain Plug
Torque to 10 ft/lbs

Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warrantied if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.