



2753 Michigan Road • Madison, Indiana 47250 • 855-743-3427

## INSTALLATION INSTRUCTIONS

### Polaris Calibration Kit

**Fits: 2016-2022 Polaris High Lifter RZR 1000 XP-4**  
**30-32" Tires**  
**0-3000ft Elevation**

**ITEMS INCLUDED:**

Drive Spring – Brown  
Driven Spring – Red  
Weights – WEDGEZZ 78  
Driven Belt – 1148 Series  
Decals  
Instructions

**TOOLS NEEDED:**

Floor jack & safety stands  
Drive clutch puller  
Driven clutch compression tool  
3/8" metric socket set  
7/8" socket 1/2"  
26mm or 1" socket 1/2"  
15mm socket  
Torx set  
Allen set  
Misc. normal shop tools

**Make sure that you compare year/model on instruction sheet to the unit you have.**  
**Do Not attempt this install w/o proper tools or damage to clutches & injury could occur.**  
**Do Not attempt this install if you are not qualified. Injury could occur.**  
**Inspect Drive/Driven clutch faces before you install kit. Repair/Replace, as necessary.**

**Need help with your installation?**



sales@superatv.com



www.superatv.com



1-855-743-3427



8:00am - 8:00pm EST M-Th  
8:00am - 7:00pm EST Friday  
9:00am - 2:00pm EST Saturday

**Read instructions and view illustrations before beginning.**

*Thank You*

*For Choosing*



Remove air tube using 8mm & 10mm socket.  
Remove clutch cover screws (8) with 8mm socket.  
Remove drive clutch retainer bolt (7/8" socket).  
Remove drive clutch using clutch puller. Hand thread to get started.  
Use 26mm or 1" socket on puller. OEM torque spec is 96lbs, so clutch is on there.  
Remove driven clutch bolt (15mm socket)  
Remove clutches/belt from machine.  
Remove drive clutch cover bolts (6).  
Clean/wipe/blow dust from drive clutch assembly.  
Wipe faces of clutch sheaves with contact cleaner on a rag.  
Install supplied weights in drive clutch.  
Install supplied **Brown** spring in clutch.  
Install cover aligning X on cover to X on clutch spider.  
Compress cover/spring and install bolts and torque to 10lbs.  
Clean/wipe/blow dust from driven clutch assembly.  
Install driven clutch sheave compression tool.  
Tighten tool cage slightly against flat area.  
Mark X on clutch for alignment.  
Remove 4 torx screws (#25). Slight heat will help.  
Remove helix.  
Release pressure on spring and remove spring.  
Install supplied **Red** driven spring in clutch.  
Install helix lining up installing machine roller area around rollers. Non-machined area lines up with inside clutch raised area.  
Note: Order Non-EBS helix to eliminate engine breaking and slow speed chattering.  
Tighten tool cage slightly against flat area. Align holes.  
Install driven clutch assembly on unit.  
Install retainer bolt and finger tighten to hold clutch assembly on shaft.  
Install drive belt on driven clutch with part numbers so that you can read them.  
Install drive clutch through belt and onto engine stub shaft.  
Tighten driven clutch bolt to factory spec 40lbs.  
Install drive clutch bolt and torque to 96lbs.

**Verify that all items have been properly installed & properly torqued.**

Install clutch cover.

**After verifying that all items have been properly installed/torqued start engine.**

Engagement should be 2-2200rpm after initial engagement.

Top rpm should be 81-8300rpm under full throttle, normal operating conditions.

**Re-torque drive clutch/driven clutch bolts to proper Polaris specs after 100 miles of operation.**

Failure to do so could cause future damage to the clutches or injury to the operator.

If you have any problems/questions on this kit, **contact us by email** at SUPERATV.COM

## **TECH TIPS:**

1. Contact SuperATV if you add larger/heavier tires as this changes the clutch calibration.
2. Drain water out of clutch cover after washing unit or driving thru deep water before operating. as this could cause a flat spot/damage belt and wear the drive clutch causing a clutch face Groove/damage.
3. Clean clutches at least once a season for normal maintenance.
4. Under Severe conditions such as MUD BOG riding/racing, clean clutches daily.
5. Do not install partial kit as kit was designed to work correctly using all enclosed items.
6. Do not mix other company's parts with kit as this could cause damage/improper operation.

**Torque Specs:** Companies change specs so verify any/all bolt tightening specs by checking with your BRP dealer, service manual, owners manual, or Polaris Industries