







Parts List	Tools List
<ul style="list-style-type: none"> <li>(1) B&amp;M Super 8.8 Diff Cover</li> <li>(2) 1/2"-13 Load Bolts</li> <li>(2) 1/2"-13 Jam Nuts</li> <li>(1) 1/2" NPT Fill Plug</li> <li>(1) 1/4" NPTF Drain Plug</li> <li>(9) M10-1.50 x 25mm Bolts</li> <li>(9) M10 Flat Washers</li> <li>(1) 6" Plastic Tie Wrap</li> </ul>	<ul style="list-style-type: none"> <li>Jack &amp; Jack Stands</li> <li>Drain Pan</li> <li>Rags</li> <li>RTV Silicone Gasket Maker</li> <li>Gear Oil</li> <li>Gear Oil Pump</li> <li>3/8" Ratchet &amp; 3" Extension</li> <li>1/4" Allen</li> <li>13 mm Socket</li> <li>3/4 Socket</li> <li>Flat Blade Screwdriver</li> <li>8 mm Allen</li> <li>3/8 Allen</li> </ul>

**IMPORTANT: RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE**