2753 Michigan Road • Madison, Indiana 47250 • 855-743-3427

INSTALLATION INSTRUCTIONS

Rear Trailing Arms: for Can-Am Maverick R (2024+)

- Do not discard packaging until product has been successfully installed.
- Keep all components removed from machine.
- Driver side installation shown in illustrations.



Driver Arm



Passenger Arm

Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warrantied if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.

Need help with your installation?

sales@superatv.com

www.superatv.com

1-855-743-3427

8:00am - 8:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday

Read instructions and view illustrations before beginning.

Thank You For Choosing

© 2024 SuperATV.com®. All Rights Reserved.


remove
remove
remove
remove


remove
drill out Rivets


remove Cover


remove Caliper


remove Axle hardware


remove Knuckle
remove


if present remove Harness
from Hose Support
remove Brakeline from
Hose Support
if present disconnect Link
(reconnect to new Arm)


support Rear Trailing Arm


remove


drill out Rivets and remove
Hose Support

- Secure Hose Support to Driver Arm with hardware shown; tighten.



- Install Driver Arm to Frame with hardware shown.
- Do not tighten if interference with Rivet occurs; see below.







- Secure Shock to Driver Arm with hardware shown; tighten.
- Secure Swaybar Link to Driver Arm with stock hardware; tighten.







- Reinstall Knuckle to Driver Arm with hardware shown; tighten.
- Reinstall Hub and Disc and secure Axle; tighten.





M14 x 80mm



M14 Nut

- Secure Lower Radius Arm to Driver Arm with hardware shown; tighten.



- Secure Upper and Middle Radius Arms to Knuckle with previously removed hardware; tighten.



- Reinstall Caliper with stock hardware; tighten.



- Reinstall Cover with stock hardware; tighten.



- Secure Brakeline to Driver Arm with hardware shown; tighten.
- Place Brakeline, and Harness if applicable, into Hose Support.



- Repeat steps for Passenger Arm installation.